

INSTALLATION & MAINTENANCE MANUAL

TPB14EMSLED

GENERAL INSTRUCTIONS

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.

These instructions should be used to aid installation of the following product:

TPB14EMSLED

SAFETY

- This product must be installed in accordance with the latest edition of the IEE Wiring Regulations (BS7671) and current Building Regulations. If in any doubt, consult a qualified electrician
- · Please isolate mains prior to installation or maintenance
- Check the total load on the circuit (including when this luminaire is fitted) does not exceed the rating of the circuit cable, fuse or circuit breaker
- Please note the IP (Ingress Protection) rating of this product when deciding the location for installation
- This product is Class II double insulated
- This product is IP44 rated

INSTALLATION

Note - Microwave sensors may not be suitable for all installations, for example enclosed spaces, as they are able to detect movement through non-metallic surfaces like plasterboard and thin doors.

- Provide power to the required point of installation (refer to BS7671 for correct cabling methods).
- Suitable IP rated junction boxes should be used where required
- Remove the diffuser by rotating the bezel anti-clockwise (see Fig. 1)
- Loosen the three LED plate screws (see Fig. 2)



 Remove the LED plate and disconnect from the driver and emergency inverter via the DC sockets (see Fig. 3)






Fig. 3

- Drill the fixing holes in the rear of the fitting. Mark the location of the fixing holes and drill ensuring not to infringe with any gas/water pipes or electrical cables
- Feed the mains cable through the rubber grommet to retain IP rating, and secure the baseplate to the surface
- Connect the luminaire to the mains supply ensuring the correct polarity is observed (see Fig. 4):
 L Permanent Live, K Switched Live (brown), N Neutral (blue)



- The additional terminal called Slave Live (SL) is available to enable the sensor to power on additional luminaires. A max. of 500W LED load can be controlled by the sensor
- · See below for adjustment of the sensor settings
- Reconnect the LED plate to the driver and inverter via the DC sockets
- · Connect the battery to the socket on the emergency inverter
- · Refasten the three LED plate screws
- · Reattach the diffuser by rotating clockwise
- · Switch on and check for correct operation, ensuring the green indicator LED is illuminated
- We recommend, on commissioning the installation, a minimum charge period of 24 hours before carrying out an emergency duration test
- If the batteries have been left in a discharged state for an extended period, we recommend that one or more charge and discharge cycles are completed which should help to restore the battery capacity

SENSOR LAYOUT



WARNING

This product must be disconnected from the circuit if subjected to any high voltage or insulation resistance testing. Irreparable damage will occur if this instruction is not followed.

GENERAL

This product contains a light source of energy efficiency class F to Regulation (EU) No 2019/2015.

This product contains an LED light source which can be replaced by the end user and a control gear which can be replaced by a professional.



Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents which may damage the product.

Do not use any source of high-pressure washers to maintain or clean this luminaire.

This product is non-dimmable.

This product should be dismantled for disposal when it reaches the end of its life. Please see website for dismantling instructions.

This product should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist.

The batteries in this luminaire are Nickel Cadmium and must be disposed of correctly. Please contact the local authorities for the disposal of this toxic waste

WARRANTY

This product has a warranty of 3 years (excluding battery) from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations (BS7671), improper use, or removal of the batch code will invalidate the warranty. If this product should fail within its warranty period, it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.

TESTING FOR EMERGENCY LUMINAIRES

- Recommended routine test procedure in accordance with BS5266
- Daily check check LED charge indicator is illuminated
- Monthly functional test simulate a mains supply failure for approx. 30 seconds by operation of key switch
 or switching off circuit breaker. Ensure normal supply is restored after test and ensure charge indicator is
 illuminated
- Annual 3-hour duration test simulate a mains supply failure for 3-hour continuous test by operation
 of key switch or switching off circuit breaker. Ensure normal supply is restored after test and ensure charge
 indicator is illuminated
- If the luminaire fails any of the above tests, please contact a qualified electrician. See below for test record sheet

TEST RECORD SHEET											
INITIAL COMMISSIONING 3 HOUR TEST		SIGNED					DATE				
MONTH	TEST	FIRST YEAR		SECOND YEAR		THIRD YEAR		FOURTH YEAR		FIFTH YEAR	
		SIGNED	DATE	SIGNED	DATE	SIGNED	DATE	SIGNED	DATE	SIGNED	DATE
1	FUNCTIONAL										
2	FUNCTIONAL										
3	FUNCTIONAL										
4	FUNCTIONAL										
5	FUNCTIONAL										
6	FUNCTIONAL										
7	FUNCTIONAL										
8	FUNCTIONAL										
9	FUNCTIONAL										
10	FUNCTIONAL										
11	FUNCTIONAL										
12	3 HOUR										

Installed by: Installation date:

Contact number:



















ML Accessories Limited LU5 4LT www.mlaccessories.co.uk