

WEDGE ANCHORS

CODE WA10,WA8,WA6



A deformation controlled Drop-in Anchor suitable for use in concrete over ≥ 20 N/mm

Installation -

1. Drill correct diameter hole to the recommended depth
2. Clean hole thoroughly with nylon brush and blow out hole using a hand pump
3. Insert anchor and drive down the plug until the setting tool shoulder meets the anchor
4. tighten bolt with a torque wrench to recommended assembly torque

Thread	Shield/Hole	Anchor Length	Min Hole Depth	Internal Thread Length	Pack/Qty
M6	8mm	25mm	25mm	9mm	100
M8	10mm	30mm	30mm	12mm	100
M10	12mm	40mm	40mm	16mm	100

Thread	Shield/Hole	Shield/Hole Depth	Embedment Depth	Centre Spacing	Edge Distance	Rec. Tensile load	Rec. Shear Load	Rec. Tightening Torque
M6	8mm	25mm	7-8mm	70mm	95mm	2.4 KN	1.9 KN	4 NM
M8	10mm	30mm	9-10mm	75mm	100mm	3.2 KN	2.3 KN	9 NM
M10	12mm	40mm	11-12mm	100mm	135mm	4.9 KN	2.8 KN	17 NM

Finish BZP Zinc Plated