

Wood Jigsaw Blades (HCS)

MATERIAL RECOMMENDATIONS

- Hard and Soft Woods
- Plywood
- Plastics
- OSB
- Laminated Particle Board (5 - 30mm thick)

BLADE DIMENSIONS

- Overall Length: 100mm
- Working Length: 76mm
- Thickness: 1.5mm

USER INSTRUCTIONS

- Keep a firm grip of the power tool, pushing it onto the surface to prevent chattering.
- If possible, clamp the material to be cut.
- Use the correct blade for the material being cut.
- Be careful when handling cut material - burrs may be present.
- Avoid tight turns when cutting as this puts stress on the blade and breakages are possible.
- Adjust the speed to suit the material being cut. In general, the softer the material the higher the speed. Tough materials should be cut at lower speeds.



Wear hand
protection



Wear eye
protection



Wear hearing
protection



Wear a face mask



T-Shank



Use in a jigsaw
machine