

Energizer®

PRO SERIES

FOCUSING HYBRID HEADLAMP

The **Energizer Pro Series Focusing Hybrid Headlamp** is an innovative headlamp solution within the Pro Series portfolio. Featuring bright, durable and energy efficient LED technology, users get a bright, lightweight, hands-free solution with ample run time capability. High CRI LED provides the user with clear, high-definition color clarity. Featuring patented Digital Focus, users can easily broaden or narrow their field of vision with a simple button press. With a comfortable, adjustable head strap, anti-glare design, and pivoting head to direct light exactly as needed, this headlamp is a perfect on the job solution.

HIGH CRI
FOR HIGH DEFINITION
COLOR CLARITY

6
MODES



FOR WHITE MODES
& DIGITAL FOCUS

FOR
GREEN
MODES



**HYBRID
POWER**

RECHARGEABLE BATTERY
CHARGING INDICATOR


RECHARGEABLE




ALSO RUNS ON
3 AAA BATTERIES



**UNIVERSAL
HELMET
ATTACHMENTS**



ATTACH CLIPS TO FRONT



ATTACH CLIPS TO BACK

OPERATING INSTRUCTIONS

HOW TO USE:

FOR WHITE MODES:

Press right button for white modes.

- Press 1 time for High.
- Press 2 times for Med.
- Press 3 times for Low.

FOR DIGITAL FOCUS:

Press and hold right button on high or low to adjust the width of the beam. Release to set focus setting.

FOR GREEN MODES:

Press left button for green modes.

- Press 1 time for Green.
- Press 2 times for Flashing Green.

OFF After 2 seconds in any mode, next press will be off.

HOW TO POWER:

**HYBRID POWER: RUNS ON PRIMARY BATTERIES (AAA)
OR A RECHARGEABLE BATTERY**

TO OPEN BATTERY DOOR:

- Pivot headlamp forward.
- Lift latch to unlock battery door.
- Close and press latch to lock.

NOTE: Primary batteries and rechargeable battery cannot be used at the same time.

TO USE PRIMARY BATTERIES (AAA):

- Open battery door and follow orientation instructions inside battery compartment to replace the 3 AAA batteries.

TO USE THE RECHARGEABLE BATTERY:

- Insert the rechargeable battery following the orientation marks on the battery and battery compartment.
- For charging, the rechargeable battery can be left in the light or removed.
- Light must be turned off during charging if rechargeable battery is left inside the light.
- Light may operate on primary batteries while rechargeable battery charges outside of the light.
- To charge use included USB cord and plug battery into any USB charging port.

RECHARGEABLE BATTERY CHARGING INDICATOR:

- A charge indicating light is located by the USB port and will illuminate when the USB charging has started.

- Red = Charging
- Green = Charging complete

DESIGN FEATURES:

- Attaches to hard hats or helmets

TO ATTACH:

1. Ensure surface of the helmet is clean and oil free.
2. Adjust head strap to fit size of hard hat/helmet.
3. Place head strap around hard hat/helmet and position accordingly.
4. Remove film from one side of the double-sided tape and attach to each clip, keeping film over other side.
5. Fit two of supplied attachment clips on the front of hard hat/helmet. (Figure A)
6. For front two clips, remove film off other side of double-sided tape and attach to hard hat/helmet to hold in place.
7. Fit two of supplied attachment clips on back of hard hat/helmet. (Figure B)
8. For rear two clips, remove film off other side of double-sided tape and attach to hard hat/helmet to hold in place.
9. Head strap can be removed and reattached to helmet without removing the attachment clips.

