

PRODUCT ASSEMBLY INSTRUCTIONS



Congratulations on the purchase of your new Quikreel.



Inside the box you will find five main components for assembly.



Take the components out of the box.



To assemble the bottom of the Quikreel attach the gland with the cap to the pipe and feed through the bottom blank disc.



Place the rubber seal on the bottom of the disc and screw the lock nut to the gland.



Tighten the gland onto the pipe.



This completes the bottom part of the Quikreel.



These are the attachments to assemble the top of the Quikreel.



Feed the gland through the top labelled disc.



Place the rubber seal on the bottom of the disc and screw the locking nut to the gland.



This completes both parts of the Quikreel.



Place your cable drum onto the bottom disc.



Screw the top disc onto the cable drum and tighten.



Your Quikreel is ready to use. Happy dispensing.